



EGHOLM


One seater (no armrest)
8230_1S




One seater (left armrest)
8230_1SL




One seater (right armrest)
8230_1SR




Corner
8230_C




Chaiselong (left armrest)
8230_CHL




Chaiselong (right armrest)
8230_CHR



Open end Left
8230_OPL



Open end Right
8230_OPR



Pouf
8230_P

